Under the web-address https://www.process-informatik.de are product specific
documentations or software-driver/-tools available to download.
If you have questions or suggestions about the product, please don't hesitate to contact us.

Process-Informatik Entwicklungsgesellschaft mbH
Im Gewerbegebiet 1
DE-73116 Wäschenbeuren
+49 (0) 7172-92666-0

info@process-informatik.de
https://www.process-informatik.de

Menutree Website: **QR-Code Website:**

+ Products / docu / downloads
  + Hardware
    + Time
      + DCF-amplifier


Please make sure to update your drivers before using our products.

Data backup S5-PLC on SD-card

S5-PLC triggered DB-backup/-restore without additional PC via PG-socket and Ethernet on SD-card

---

Bus-connector with diagnostic function

Bus problems and no reason apparent?
  Connect the diagnostic-bus-connector to the "suspicious" PLC and read the possible cause of the fault using the blink-code:
 - 5V voltage missing/out of specification
 - possible short-circuit in the bus
 - No bus-activity on the PLC
 - Wrong termination
 - Bus is open
  ...
  The bus-connectors of the "DiagConn"-series indicate all of these possible causes of the malfunction. The bus-connector is available in 90°, 45° and 0°-versions. The connectors can be attached instead of the "normal" bus-connectors. There does not have to be a fault, the plugs can generally also be used in the bus and you can later find the cause of any

Remote-maintenance of a Siemens-controller with network-connection via secure VPN-tunnel and scalable firewall

Independent operation through power-pack-supply

You want for e.g. moving around your system/control and need a 24V-DC-supply for your access-point ALF-UA?
   With USB-power-cable and a USB-power-bank/-accu, the problem can be solved immediately with little effort.

View information from the connected bus-system in plain text without using the Simatic-Manager or TIA-Portal. With the connection-menu you get the list of reachable nodes, marked in color whether it is an "active bus-participant", is a "candidate for inclusion in the bus" or a "passive bus-participant".

You can also see whether cyclic bus-parameter-protocols have been received, you are "in the bus" yourself, the bus-address of the participant recognized as a "direct participant" (on which the S7-LAN is located) and whether the contained modules such as "variable control", "gateway-coupling",... actively communicate.

Interface for Mitsubishi Melsec Fx- & A-series

Changes to Mitsubishi PLCs but no interface cable?

Use the SC09 cable to connect the PC to the Mitsubishi MELSEC FX & A series. Any PLC with an RS-422 interface can be connected. Including adapter cable for 8-pin DIN connection, firmly attached so that it can never be forgotten. One cable for both types, universal to the Mitsubishi PLC.