Handling-short-instruction V1.0 for

ALF-UA
industrial Wifi-router

Connectors:

WIFI

Power 24V DC

on: WIFI active
flashing: WIFI-communication running

Power-ON

PC for configuration or
device/PC for communication

To internet-router for router-
mode

Power connection:

Voltage: 24 V DC ± 20%
Power: 1,2W

Pinning voltage connector:

0V   +24V DC ± 20%

Initial start-up:

– ALF-UA creates a WLAN network with an SSID „ALF-UA"
with active DHCP master (laptop is automatically assigned an IP address)
– Connect laptop to this WiFi network and open with
browser webserver with IP: http://192.168.2.1

or

– Connect the PC to the LAN port using a LAN cable
– PC must be in the 192.168.2.xxx subnet
– Open with browser the webserver with IP: http://192.168.2.1

User name: admin
Password: admin

Home page :


Menu network :

4 operating modes are possible with the ALF-UA :

– AP Router   is an access point with LAN and WAN port (separate subnets)
– AP Bridge   is ACCESS-Point with 2 LAN sockets (WIFI and LAN sockets bridged)
– Client Router   is WIFI client with LAN and WAN port (separate subnets)
– Client Bridge   is WIFI client with 2 LAN sockets (WIFI and LAN sockets bridged)

==> Access point opens a WIFI network, client connects to an existing WIFI network .

All 4 modes can be parameterized and saved in parallel, you determine which mode is active :

You need the following modes for the following situations :

Situation	AP Router	AP Bridge	Client Router	Client Bridge	Peculiarity
With a laptop around the S5/7-PLC + ALF-UA	X	---	---	---	PLC via S5/7-LAN to LAN port
With a laptop around the S5/7-PLC + ALF-UA	---	X	---	---	PLC via S5/7-LAN to LAN port Another LAN participant on the WAN port
Bring the S5/7-PLC or LAN device into the existing WIFI network	---	---	X	---	PLC via S5/7-LAN / LAN-device on LAN port
Bring the S5/7-PLC or LAN device into the existing WIFI network	---	---	---	X	PLC via S5/7-LAN / LAN-device on LAN port Another LAN participant on the WAN port
Extend LAN route Attention: 2 devices required		X		X	One device as AP Bridge and the second as Client Bridge

After selecting the configuration, save it in the device and after restarting the device, it can be used in the selected operating mode.

You can find more about the operating modes in the device manual on the product page of the ALF-UA .

Under the web-address https://www.process-informatik.de are product specific
documentations or software-driver/-tools available to download.
If you have questions or suggestions about the product, please don't hesitate to contact us.

Process-Informatik Entwicklungsgesellschaft mbH
Im Gewerbegebiet 1
DE-73116 Wäschenbeuren
+49 (0) 7172-92666-0

info@process-informatik.de
https://www.process-informatik.de

+ Products / docu / downloads
  + Hardware
    + Programming devices
     + S7
      + WLAN/WIFI
       + Profinet PLCs / Ethernet-CPs
        + ALF-Devices
         + ALF-UA table version

Please make sure to update your drivers before using our products.