

Under the web-address <https://www.process-informatik.de> are product specific documentations or software-driver/-tools available to download.
If you have questions or suggestions about the product, please don't hesitate to contact us.

Process-Informatik Entwicklungsgesellschaft mbH

Im Gewerbegebiet 1

DE-73116 Wäschenbeuren

+49 (0) 7172-92666-0

info@process-informatik.de

<https://www.process-informatik.de>

Menutree Website:

- + Products / docu / downloads
- + Hardware
- + Analysis technic
- + OSM-HMG




QR-Code Website:




Please make sure to update your drivers before using our products.

Wireless around the S5-PLC




Move wirelessly around the S5-PLC and communicate for example ONLINE in the status

Data backup S7-PLC PN-port on FTP-server via dig. IO



Via digital input triggered DB-backup/-restore without additional PC via PN-port to FTP-server

Data backup S7-PLC over MPI/Profibus on FTP-server via dig. IO




Via digital input triggered DB-backup/-restore without additional PC via MPI/Profibus to FTP-server

Remote-maintenance Siemens-S5-PLC with firewall



Remote-maintenance of a Siemens-S5-controller with S5-LAN++ on PD-port via secure VPN-tunnel and scalable firewall

Doubling of PPI/MPI/Profibus-interface without bus-connector



Do you have a single control with panel in use and have to accomplish a little modification in the control program? No problem, plug the T-Connector on the PLC, the panel and PC to the device and then both participants can work with the PLC without annoying bus-cable tapering and interconnections.

Display diagnostic-buffer without Simatic-Manager

Diagnose für Subsystem 42 (diagnostic)		
<div> <div>Diagnose-Identifikation</div> <div> <div>Produktname</div> <div>Produkttyp</div> <div>Produktversion</div> </div> </div>		
<div> <div>Diagnose-Zustand</div> <div> <div>Diagnose-Zustand</div> <div>Diagnose-Zustand</div> <div>Diagnose-Zustand</div> </div> </div>		
<div> <div>Diagnose-Log</div> <div> <div>Diagnose-Log</div> <div>Diagnose-Log</div> <div>Diagnose-Log</div> </div> </div>		
<div> <div>Diagnose-Parameter</div> <div> <div>Diagnose-Parameter</div> <div>Diagnose-Parameter</div> <div>Diagnose-Parameter</div> </div> </div>		
<div> <div>Diagnose-Status</div> <div> <div>Diagnose-Status</div> <div>Diagnose-Status</div> <div>Diagnose-Status</div> </div> </div>		
<div> <div>Diagnose-Alarm</div> <div> <div>Diagnose-Alarm</div> <div>Diagnose-Alarm</div> <div>Diagnose-Alarm</div> </div> </div>		
<div> <div>Diagnose-Event</div> <div> <div>Diagnose-Event</div> <div>Diagnose-Event</div> <div>Diagnose-Event</div> </div> </div>		
<div> <div>Diagnose-Error</div> <div> <div>Diagnose-Error</div> <div>Diagnose-Error</div> <div>Diagnose-Error</div> </div> </div>		
<div> <div>Diagnose-Warning</div> <div> <div>Diagnose-Warning</div> <div>Diagnose-Warning</div> <div>Diagnose-Warning</div> </div> </div>		
<div> <div>Diagnose-Info</div> <div> <div>Diagnose-Info</div> <div>Diagnose-Info</div> <div>Diagnose-Info</div> </div> </div>		

Via the connection-menu and the included bus-device-display, it is possible to display the diagnostics buffer of the respective device without having to open Simatic-Manager or TIA-Portal separately.

The data received from the module is output directly in one piece without the hassle of changing tabs. All data at a glance.